



## RS 50/F INSTALLER'S GUIDE

BEFORE APPLYING POWER ensure that slide switch SW1 is in position "P" (ie. up).

When power is first applied to the panel all four STATUS lights flash and the internal siren is sounding. Press \* twice, enter the "USER CODE" ( 4 3 2 1 ), at this point the siren will stop.

### Factory set codes

The panel reverts to these codes after any TOTAL power failure.

**USER CODE** = 4 3 2 1

switches system ON & OFF.

**DURESS CODE** = 9 9 9 9

switches system OFF and gives SILENT P. A. output.

**BOSS CODE** = 0 0 0 0

allows changing of all codes except ENGINEER.

**CHANGING USER CODE** enter 0 0 0 0 \* 2 (change access) the fault tone will sound. Enter new code (any 4 digits in any order eg. 1 2 1 2 ) after the last digit is entered the siren will stop.

**CHANGING DURESS CODE** enter 0 0 0 0 \* 1 (change duress) the fault tone will sound.

Enter new code (any 4 digits in any order eg. 2 1 2 1 ) after the last digit is entered the siren will stop.

**CHANGING BOSS CODE** enter 0 0 0 0 \* 3 (change boss) the fault tone will sound. Enter new code (any 4 digits in any order eg. 8 0 8 0 ) after the last digit is entered the siren will stop.

**NOTE YOU HAVE JUST CHANGED THE BOSS CODE - THIS NEW CODE REPLACES THE FACTORY SET CODE OF 0 0 0 0 !!!**

**ENGINEER CODE** = 6 6 6 6

### Factory set programme

- Zone 1 Final Exit
- Zone 2 Exit Route
- Zone 3 TAMPER INDICATION ONLY
- Zone 4 Guard, on in FULL & PART only
- Zone 5 Guard, on in FULL & PART only
- Zone 6 Guard, on in FULL & CHIME only

EXIT TIME = 20 seconds (when used eg. PART) ENTRY TIME = 40 seconds

BELL START = ZERO minutes BELL STOP = 15 minutes

### SYSTEM FUNCTIONS



#### SETTING SCHEME

- FULL Final door set
- PART Timed exit with quiet tone, zone 6 deselected and BELLS ONLY EXCEPT P. A..
- CHIME Instant set, zones 2, 3, & 4 deselected, internal siren only.
- CUSTOMER RESET BELLS AND STROBE ON P. A.

### SIGNALLING FUNCTIONS

- AUTO RESET 3 TIMES automatically deselected any permanently faulty zone or zones.
- CHIME IS NON-LATCHING TAMPER SOUND: INTERNAL SIREN STOPS WITH BELL.

# CONNECTIONS




## TERMINAL DESCRIPTIONS

### CB1 (from Left)

- 1 Switched +ve out-put
- 2 (S) -ve out-put in alarm, not affected by bell timer.
- 3 (D) -ve hold off and anti-tamper feed.
- 4 (C) -ve anti-tamper return.
- 5 (B) -ve output in alarm, subject to cut off by bell timer.
- 6 (A) +ve common and hold off.
- 7 Com -ve for feed to Space Detectors.
- 8 13.68 +ve feed to Space Detectors. 250mA Max.


### CB2

- 1 -ve out anti-tamper feed
- 2 -ve in anti-tamper return
- 3 +ve in detection loop return
- 4 +ve out detection loop feed



### CB 3 & 4

- 1 -ve out anti-tamper feed
- 2 -ve in anti-tamper return
- 3 +ve in detection loop return
- 4 +ve out detection loop feed
- 5 -ve out anti-tamper feed
- 6 -ve in anti-tamper return
- 7 +ve in detection loop return
- 8 +ve out detection loop feed



### ZONE 4

### ZONE 6

### PL3 (MIDDLE LEFT of PCB) (from bottom)

- |              |                        |
|--------------|------------------------|
| 1 Common -ve | 5 Intruder +ve         |
| 2 NOT USED   | 6 NOT USED             |
| 3 Set +ve    | 7 Common +ve           |
| 4 P.A. +ve   | 8 Line Sense Input -ve |

This plug is provided for the connection of remote signalling equipment, e.g. digital communicator, with the use of the eight way IDC communications plug supplied which has No. 1 marked on it to correspond with No. 1 above. In the event that the system is intended to be "Bells Only" and it is required to extinguish the NO LINE LED, insert a link of wire between 1 and 8 on the communications plug and fit it to PL3.

PL2 (TOP LEFT of PCB) (from bottom) for remote setting point.

### CONTROL PANEL

### REMOTE SETTING POINT

- 1 Speaker +ve
- 2 Speaker -ve
- 3 Open light
- 4 Fault light
- 5 Keypad
- 6 Keypad
- 7 Keypad
- 8 Keypad

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8

# PROGRAMMER'S GUIDE

## TO ENABLE PROGRAMME CHANGES TO BE MADE

1. Slide SW1 down to position "R".
2. Press push button SW2, siren will start.
3. Slide SW1 up to position "P".
4. Enter [\*] [6] [6] [6] [6] this will silence the sounder.
5. Slide SW1 down to position "R".
6. Press [\*] twice.
7. Enter [1] [2] [3] [4]

**N.B.** It is only necessary to carry out the above procedure when an RS50 is to be re-programmed for the **FIRST** time.

## RE-PROGRAMMING RS 50/F

1. ENSURE THAT THE PANEL IS **NOT SET** i.e. the **OPEN** light is **ON**.
2. Remove the lid, ensure that the **ENGINEER SWITCH** is down (if it is up at this time the system is self configuring and cannot be re-programmed).
3. Slide **ENGINEER SWITCH** up, enter **ENGINEER CODE** on the keypad (factory 6666), this action will silence the siren and bring on the **NIGHT SET TONE**.
4. Re-programme as required.

When in **ENGINEER MODE**

[\*] moves to next block # moves to next position in block

**TONES ARE USED AS BLOCK POINTERS**

## ZONES

When the **NIGHT SET TONE** is sounding you are in the **ZONE BLOCK**.

The four **STATUS LIGHTS** indicate the position in the block.

OPEN = ZONE 4                  FAULT = ZONE 5                  NO MAINS = ZONE 6

The first three zones are fixed and cannot be re-programmed.

1 = FINAL EXIT                  2 = EXIT ROUTE                  3 = TAMPER INDICATION

**ZONE LIGHTS 1 to 6** display the programme and can be switched on and off by pressing the associated button. Lights 1 to 3 are used in combination to determine the **ZONE FUNCTION**.

## ZONE FUNCTIONS

DO NOT USE	1	2	3					
DO NOT USE	0	2	3					
P.A.	1	0	3					
24 Hour	0	0	3					
FINAL EXIT	1	2	0					
EXIT ROUTE	0	2	0					
GUARD D/KNOCK	1	0	0					
GUARD	0	0	0		4	5	6	7

