



Put the meter one Probe Black other on grey

Touch the Black & Grey wire together
The meter should show zero

If you get zero – then you know the Black & Grey wire are good in the wall

Repeat – Black and Brown see if that is zero – if so then all good