

## Woodscrew conversion chart

Flat (Csk) head screws are measured in total length, Round/Pan head screws are measured from underneath the head, ie. The part that is inserted into the wood.

Also below is a guide to which Pozi Bit could be used, PZ2 most popular

Gauge (mm)	Length (mm)	Imperial Size
3mm <b>(Pozi PZ1)</b>	12	4 x 1/2
	16	4 x 5/8
	20	4 x 3/4
	25	4 x 1
	30	4 x 1 1/4
	40	4 x 1 1/2
3.5mm <b>(Pozi PZ2)</b>	12	6 x 1/2
	16	6 x 5/8
	20	6 x 3/4
	25	6 x 1
	30	6 x 1 1/4
	40	6 x 1 1/2
4mm <b>(Pozi PZ2)</b>	12	8 x 1/2
	16	8 x 5/8
	20	8 x 3/4
	25	8 x 1
	30	8 x 1 1/4
	35	8 x 1 3/8
	40	8 x 1 1/2
	45	8 x 1 3/4
	50	8 x 2
	60	8 x 2 3/8
	70	8 x 2 3/4
4.5mm <b>(Pozi PZ2)</b>	25	9 x 1
	30	9 x 1 1/4
	35	9 x 1 3/8
	40	9 x 1 1/2
	45	9 x 1 3/4
	50	9 x 2
	60	9 x 2 3/8
	70	9 x 2 3/4
	75	9 x 3

Gauge (mm)	Length (mm)	Imperial Size
5mm <b>(Pozi PZ2)</b>	25	10 x 1
	30	10 x 1 1/4
	35	10 x 1 3/8
	40	10 x 1 1/2
	45	10 x 1 3/4
	50	10 x 2
	60	10 x 2 3/8
	70	10 x 2 3/4
	75	10 x 3
	80	10 x 3 1/4
	90	10 x 3 1/2
6mm <b>(Pozi PZ3)</b>	100	10 x 4
	30	12 x 1 1/4
	40	12 x 1 1/2
	50	12 x 2
	60	12 x 2 3/8
	70	12 x 2 3/4
	75	12 x 3
	80	12 x 3 1/4
	90	12 x 3 1/2
	100	12 x 4
	110	12 x 4 3/8
130	120	12 x 5 1/8
	150	12 x 6