

Franke Moselle Tap

Replacing Cartridge and O-Rings

Replacing the cartridge

Before replacing the cartridge, you will need to turn the water off. You'll need to remove the indicator from the handle (1) and then remove the handle screw (2) by using a crosshead screwdriver. Once you've removed the handle (3), you can use an adjustable spanner to unscrew the valve (4). You'll then be able to fit the replacement valves.

Replacing the o rings

To replace the o rings, you'll need to unscrew the collar (5) at the base of the spout (6) by unscrewing it anticlockwise. Once the collar is completely unscrewed, you can pull the spout out. You'll then be able to remove the existing o rings (7) and replace with the replacement parts.

