


## LP241 Quick Guide



LP241 has a Real Time Clock Module fitted and you will not need to set the day or time as this is automatically done for you. In addition this new model now automatically adjusts itself for BST and GMT.

### **Important Note:**

Before setting unit, press and hold the "SET" and "+" buttons for a minimum of 5 seconds to reset to defaults (display will go blank)

### **How to set up required ON/OFF times for Heating and Hot Water**

- Press SET button to display "SET PROG"
- Press YES button to display "ON 6:30 AM CH"  
Press buttons "+" or "-" to alter the first ON time
- Press SET button to display "OFF 8:30 AM CH"  
Press buttons "+" or "-" to alter the first OFF time
- Press SET button to display "ON 12:00 PM CH"  
Press buttons "+" or "-" to alter the second ON time
- Press SET button to display "OFF 12:00 PM CH"  
Press buttons "+" or "-" to alter the second OFF time
- Press SET button to display "ON 4:30 PM CH"  
Press buttons "+" or "-" to alter the third ON time
- Press SET button to display "OFF 10:30 PM CH"  
Press buttons "+" or "-" to alter the third OFF time

**You have now set your CENTRAL HEATING TIMES**

**Press SET button and you can set your HOT WATER times by following the same procedure as above.**

PRESSING THE SET BUTTON, ONE MORE TIME AFTER PROGRAMMING, SETS THE PROGRAMMER TO AUTOMATIC OPERATION.

**Operating Modes**

- Press SELECT Button for Hot Water
  - Press SELECT Button for Central Heating
- OFF = Continuously OFF  
TIMED = Switching ON/OFF as programmed  
ONCE = ON once from 1st ON to LAST OFF  
ON = Continuously ON

**Advance Button Function**

- You can temporarily override the normal switching times by pushing the button marked "ADVANCE". When in timed mode this button switches "ON" to "OFF" or "OFF" to "ON" as you require, but the normal programme switching times will not be permanently affected.